



# NVIDIA Graphics Card Settings


## Optimizing Performance for FSX




Right click on your computer desktop and select [NVIDIA Control Panel](#).



From the left panel, select [Manage 3D Settings](#).



Select the [Program Settings](#) tab.



Under “1. Select a program to customize” choose [MS Flight Simulator X \(fsx.exe\)](#).

### IMPORTANT!


If this is your first time running FSX, you will need to add FSX.exe to the list. To do this:

1. Select the Add button
2. Select Browse
3. Locate the directory where FSX was installed on your computer. The default directory is:

[C:\Program Files \(x86\)\Foresight Sports Experience\FSX.exe](C:\Program Files (x86)\Foresight Sports Experience\FSX.exe)


5

Under “2. Select the preferred graphics processor for this program” choose **High-performance NVIDIA processor**.



6

Under “3. Specify the settings for this program” scroll down to Texture filtering–Quality and select **High Performance**.



7

Click the “**Apply**” button to save your new settings.

